

The mechanically operated cable cutter has been designed especially to operate in conjunction with the PackBot EOD. The unit clamps to the gripper finger base plate and is held in position by two flat springs. The vehicle and manipulator arm do not require modifications.

To operate the cutter, insert nylon clamp plugs (with O-rings) into the bore on the lower part of each finger. Using the main camera, bring the claws into position with the wire to be cut. The replaceable wire guide assists when approaching and finally capturing the wire, even when oscillating in windy situations. The outer O-ring ensures that the cutter remains within the operational claw angle of the cutting area.

The cutter is designed for cutting insulated copper cable of 2.5 mm².

The cutter kit consists of:

Cutter insert	1 off
Wire guide	1 off
Nylon press tips	4 off
Carrying case for complete kit	1 off

Specifications are subject to change without notice

ATTENTION: The cable cutter is designed for cutting cables only. Do not cut nails, sheet metal, bolts, screws, strapping etc.



View with cable guide