

Special features:

- High performance and long range by annealed 20 mm optic
- 100% eye safe, tested class I
- Continuously adjustable beam
- High Power single mode Laser diode; Life span: 10.000 hrs
- Patented optical collimator system with four lenses
- Usable with all night vision generations
- Shockproof , splash water resistant; IP 54
- Usable even with digital night vision systems
- Optimized for use on PackBot EOD
- Weight: 112 g
- Battery: Li CR123A



The IR Laser Torch kit includes a special adjustable holder which clips onto the free side of the PackBot EOD head camera via a 3M-mushroom tape. Operators can adjust the beam in relation to the camera viewing area using an adjustment screw at the bottom side of the mounting piece.

The IR-Laser torch is battery powered. The life span of the battery allows for three hours of continuous operation.

Specifications are subject to change without notice.